



LOSS CONTROL DATA GUIDE

PRE AND POST-TRIP VEHICLE CONDITION REPORT

USE YOUR SAFETY BELT

DATE _____

LOCATION (City) _____ STATE _____ ORGANIZATION _____ TRUCK or TRACTOR-TRAILER NUMBERS _____

DRIVER _____ DRIVER _____

INSTRUCTIONS: Drivers will perform necessary inspection. A (✓) indicates satisfactory condition. An (X) indicates unsafe or improper conditions. An (O) indicates condition does not apply. Corrected deficiencies should be circled by management certifier.

INSIDE

Parking Brake (Apply)

START ENGINE

- Oil Pressure (Light or Gauge)
- Air Pressure or Vacuum (Gauge)
- Low Air or Vacuum Warning Device (Air pressure below 40 psi check on pressure build-up. Air pressure above 60 psi deplete air until warning device works. Vacuum below 8 inches Hg. check on build-up. Above 8 inches Hg. deplete vacuum until device works.)
- Instrument Panel (Telltale lights, buzzers, gauges)
- Horn
- Windshield Wiper and Washer
- Heater-Defroster
- Mirrors
- Steering Wheel (Excess Play)
- Apply Trailer Brakes in EMERGENCY
- Turn on all lights including 4-way Flasher
- Starts Property

ON COMBINATIONS

- Hoses, Connections
- Couplings (Fifth Wheel, Tow Bar, Safety Chains, Locking Devices)

EMERGENCY EQUIPMENT

- Fire Extinguishers
- Flags, Standards, Warning Lights
- Spare Fuses
- Spare Bulbs
- Chains in Season
- First Aid Kit

FRONT

- Headlights
- Clearance Lights
- Identification Lights
- Turn Signals and 4-way Flasher
- Tires and Wheels-Lugs and Serviceability

INSIDE

- Release Trailer Emergency Brakes
- Apply Service Brake (Air loss should not exceed 3 psi per minute on single vehicles, 4 psi per minute on combinations.)

SIDE

LEFT

-
-
-
-
-

RIGHT

- Fuel Tank and Cap
- Sidemarkers Lights
- Reflectors
- Tires and Wheels-Lugs and Serviceability
- Cargo Tie-downs/or Doors

REAR

- Tail Lights
- Stop Light
- Turn Signals and 4-way Flasher
- Clearance Lights
- Identification Lights
- Reflectors
- Tires and Wheels, Lugs and Serviceability
- Rear End Protection (Bumper)
- Cargo Tie-downs/Doors

MECHANICAL OPERATION

- Engine knocks, misses, overheats, etc.
- Clutch skips, grabs, other:
- Transmission noisy, hard shifting, jumps out of gear, other:
- Axles — noisy, other:
- Steering loose, shimmy, hard, other:
- Air, oil, water, leaks
- Springs broken, other:
- Brakes noisy, pulls, soft, other:
- Speedometer, Tachometer
- Tachograph, Speed Control Devices
- Other _____

OTHER

YES NO

- Equipment Inspection Enroute
- Cargo Securing Devices
- _____
- _____
- _____
- _____

START TIME	MILEAGE	END TIME	MILEAGE
REMARKS/OTHER DEFECTS			
			DRIVER'S SIGNATURE
DEFECTS CORRECTED (INITIAL)	DEFECT CORRECTION UNNECESSARY (INITIAL)	CERTIFIED BY	DATE
DEFECTS CORRECTED	<input type="checkbox"/> Yes <input type="checkbox"/> No	DRIVER'S SIGNATURE (IF DEFECTS)	DATE

The preparation and dissemination of this Loss Control Data Guide is intended only to advise management of insured firms as to how they might fulfill their responsibilities for the control of potential loss producing situations involving their premises and/or operations. It is not intended as an offer to write insurance coverage for such a condition or exposure, nor is this Data Guide intended to indicate that we will write such coverage. The Liability of Great American Insurance Company (and/or affiliates and subsidiaries) is limited to the terms, limits and conditions of the insurance policies it writes, and in providing this material, Great American assumes no Liability beyond that provided under the terms, limits, and conditions of the policies it has issued.
© Copyright 1998 by Great American Insurance Company.